PCG-Z1V/Z1VE/Z1VT PCG-Z1VAP1/Z1VAP2/Z1VA/Z1VFP PCG-Z1VCP/Z1VGP/Z1VJP/Z1VLP/Z1VTP

SERVICE MANUAL

Ver 3-2003J

Revision History

Area	Model	Line up				
Japanese	Japanese	PCG-Z1VT/P PCG-Z1V/P PCG-Z1VE	<u></u> (MA)			
American	US/ Canadian	PCG-Z1VAP1 * PCG-Z1VAP2 * PCG-Z1VA *				
. 19/10/3	Latin	PCG-Z1VFP	∠ [MA]			
	International	PCG-Z1VGP	△ [MA]			
A-i(Oi(Korean	PCG-Z1VLP	△ [MA]			
Asian/Oceania/ South Africa	Chinese	PCG-Z1VCP	2 [MA]			
	Taiwan	PCG-Z1VTP	2 [MA]			
	Thailand	PCG-Z1VJP	<u>≥</u> [MA]			

*: CTO model



Illust: PCG-Z1V/P











- Design and specifications are subject to change without notice.
- 本機の仕様および外観は、改良のため予告なく 変更することがありますが、ご了承ください。

Notebook Computer

SONY

Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United State and other countries.

The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, the AMD logo, other AMD product names and combinations thereof are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corparation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, Hotsync, PalmModem, and Palm OS are registered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrola, Inc. Other Motrola pruducts and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other name of systems, products and services in this manual are trademarks or registered trademarks of their respective owners.

In this manual, the (TM) or (R) mark are not specified.

Caution Markings for Lithium/Ion Battery - The 4 following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate.

Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- •Overcharging, short circuiting, reverse charging, multilation or incineration of the cells must be avoided to prevent one or more of the following occurrence; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

Service and Inspection Precautions

Obev precautionary markings and 1. instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the A mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270°C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

ATTETION AU COMPOSANT AYANT **RAPPORT** À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉSDANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u> <u>Page</u>	
CHAPTER 1.	SPECIFICATIONS 1-1	
	(to 1-1)	
CHAPTER 2.	BLOCK DIAGRAM 2-1	
	(to 2-1)	
CHAPTER 3.	FRAME HARNESS DIAGRAM 3-1	
	(to 3-1)	
CHAPTER 4.	EXPLODED VIEWS AND PARTS LIST	
Palmrest		
P-1	4-2	
Bottom		
B-1	4-3	
Main Board		
M-1	4-4	
LCD		
L-1	4-5	
Accessories		
A-1	4-6	
DIP Switch	4-7	
	(to 4-7)	
CHAPTER 5.	OTHERS	
5-1. The Barcode	Label 5-1	
5-2. CTO Informa	tion 5-2	<u></u> (MA)
	(to 5-2)	

History of the changes is shown as the Revision History at the end of this data.

CHAPTER 1. **SPECIFICATIONS**

		J		AM									
	PCG-Z1VT/P	PCG-Z1V/P	PCG-Z1VE	PCG-Z1VAP1*	PCG-Z1VAP2*	PCG-Z1VA*	PCG-Z1VFP						
СРИ	Pentium-M 1.7 GHz	Pentium-M 1.6 GHz	Pentium-M 1.3 GHz	Pentium-M 1.6 GHz	Pentium-M 1.7 GHz	Pentium-M 1.6 GHz	Pentium-M 1.6 GHz						
LCD	14.1SXGA+												
HDD	80GB	60GB	40GB	60GB	60GB	60GB							
MEMORY (STANDARD/MAX)	512 MB/1GB	512 MB/1GB	256 MB/768MB	512 MB/1GB	1GB/1GB	512 MB/1GB	512 MB/1GB						
On Board	512MB	512MB	256MB	512MB	512MB	512MB	512MB						
SLOT					512MB								
OPT-DRIVE	СОМВО												
Wireless LAN	0	0	0	0	0	0	0						
Bluetooth	0	0	0	0	0	0	×						
AC Adaptor	PCGA-AC16V6												
Battery	PCGA-BP2V	PCGA-BP2V	PCGA-BP2V	PCGA-BP2V	PCGA-BP4V	PCGA-BP2V	PCGA-BP2V						
os	XP Professional	XP Professional	XP Home Edition	XP Professional									

⚠ [MA]

⚠ [MA]

<u></u> (MA)

			AO		
	PCG-Z1VGP	PCG-Z1VLP	PCG-Z1VCP	PCG-Z1VTP	PCG-Z1VJP
CPU	Pentium-M 1.6 GHz	Pentium-M 1.6 GHz	Pentium-M 1.6 GHz	Pentium-M 1.6 GHz	Pentium-M 1.6 GHz
LCD	14.1SXGA+	14.1SXGA+	14.1SXGA+	14.1SXGA+	14.1SXGA+
HDD	60GB	60GB	60GB	60GB	60GB
MEMORY (STANDARD/MAX)	512 MB/1GB	512 MB/1GB	512 MB/1GB	512 MB/1GB	512 MB/1GB
On Board	512MB	512MB	512MB	512MB	512MB
SLOT					
OPT-DRIVE	СОМВО	СОМВО	СОМВО	СОМВО	СОМВО
Wireless LAN	0	0	0	0	0
Bluetooth	×	×	×	×	×
AC Adaptor	PCGA-AC16V6	PCGA-AC16V6	PCGA-AC16V6	PCGA-AC16V6	PCGA-AC16V6
Battery	PCGA-BP2V	PCGA-BP2V	PCGA-BP2V	PCGA-BP2V	PCGA-BP2V
os	XP Professional XP Professional XP Professional XP Professional XP F				

<u></u> (MA) <u></u> (MA) **△** [MA] <u></u> [MA]


<u></u> (MA]

<sup>The trademarks or registered trademarks of above table, refer to page 2.
The model that is accompanied by astarisk (*) is CTO model.</sup>


[•]本表中の商標・登録商標については、2ページをご参照下さい。

[・]機種名に(*)がつくのは、CTOモデルです。

CHAPTER 2. BLOCK DIAGRAM



CHAPTER 3. FRAME HARNESS DIAGRAM



CHAPTER 4. EXPLODED VIEWS AND PARTS LIST

The prts list is compiled by blocks of a palmrest and bottom etc.
 The sections of the parts list are different depending on the model.
 Please refer to list of contents shown in the below.

Section	Page
Palmrest	
P-1	4-2
Bottom	
B-1	4-3
Main Board	
M-1	4-4
LCD	
L-1	4-5
Accessories	
A-1	4-6
DIP Switch	4-7

・分解図と部品表は、パームレスト、ボトムなどのブロックごと に分かれています。機種によって部品表のセクションが異な りますので、詳細は右下の一覧表を参照してください。

NOTE

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown, use the parts described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
- The parts marked "#" are the parts on which barcode label is attached.

For the barcode label, refer to CHAPTER 5.

• The parts marked "&" are the "Customer Replacable parts (CRP) "that can be replaced by Field Customer Support.

Especially the parts with the <&> mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replacable Parts (CRP), or the non-targetted parts by referring to the exploded view.

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifés par une marque \(\Delta\) sont critiques pour la sécurité.

Ne les remplacer que par une piéce portant le numéro spécifié.


【使用上の注意】

- ・* 印の部品は常備在庫しておりません。
- ・図面番号のない部品は供給しません。
- ・併記部品の場合,上部記載部品をメイン部品として使用して ください。
- ・部品名称の前に**\$** 印のついた部品は, High Value Module (HVM)
- ・商品名称の前に#印のついた部品は,バーコードラベル貼付部品です。

バーコードラベルについてはCHAPTER 5を参照してください。 ・商品名称の前に&印のついた部品は、お客様窓口などでも交換 可能な Customer Replacable Parts (CRP)です。

特に <&> 印のついた部品は、使い分けが必要な部品ですので、 分解図でCoustomer Replacable Parts 対象部品か. 対象外部品か を必ず御確認ください。

△印の部品,または△印付きの点線で囲まれた部品は,安全性を維持するために重要な部品です。従って交換時は,必ず指定の部品を使用して下さい。



			Palmrest	Bottom	Main Board	LCD	Accessoris
<u> </u>		Z1VT/P	P-1	B-1	M-1	L-1	A-1
	J	Z1V/P	P-1	B-1	M-1	L-1	A-1
		Z1VE	P-1	B-1	M-1	L-1	A-1
<u> </u>	AM	U-CTO	P-1	B-1	M-1	L-1	A-1
<u> </u>	Alvi	Z1VFP	P-1	B-1	M-1	L-1	A-1
<u></u> [MA]		Z1VGP	P-1	B-1	M-1	L-1	A-1
<u> </u>		Z1VLP	P-1	B-1	M-1	L-1	A-1
<u> </u>	AO	Z1VCP	P-1	B-1	M-1	L-1	A-1
<u> </u>		Z1VTP	P-1	B-1	M-1	L-1	A-1
<u> </u>		Z1VJP	P-1	B-1	M-1	L-1	A-1

Confidential

PCG-Z1V/Z1VE/Z1VT (J)
PCG-Z1VAP1/Z1VAP2/Z1VA/Z1VFP (AM)
PCG-Z1VCP/Z1VGP/Z1VJP/Z1VLP/Z1VTP (AO)

P-1. Palmrest




17
14
1 16
13 15 M-1 16 M-1 12 B4 P
B3 B3 M-1
M-1 18
10
⊕ M-1
9 19 20
B-1 B-1 21
PCG-Z1V/T, Z1V/P, Z1VE, Z1V/P,
ZIVAPI, ZIVAPI, B3 B3 M-1
25
B3 31 (*1) B3 27 29
4 B2 B2
B2 B2 B2 30 B2
2 0
A B 31 (*1)
B2 PCG-Z1VT/P, Z1V/P, Z1VE, Z1VA, Z1VAP1, Z1VAP2 △ [MA]

Ref.No.	Part No.	Description	Ref.No.	Part No.	Description
3	1-796-622-11	TOUCH PAD	* 27	4-670-301-01	BRACKET (OD)
* 4	4-670-302-01	BRACKET (TP)	28	1-824-950-11	CABLE, FLEXIBLE FLAT (SWX132)
5	A-8117-905-A \$	SWX-132 (3) (S)	31		FILAMENT TAPE (W12X30) (*1)
6	1-824-948-11	CABLE, FLEXIBLE FLAT (TP)			, , , ,
* 8	4-670-303-01	PLATE (PARM REST L)	B2	4-673-648-01	SCREW, M2 (+B) (EG)
		,	В3	4-676-936-01	+SCREW, M2 +SPECIAL HEAD SELF S
9	4-670-975-02	SHEET (TP)	B16	4-672-834-91	SCRWE, +B EG GRIP
11	4-647-180-01	COIL SPRING			
12	1-824-947-11	CABLE, FLEXIBLE FLAT (IFX248)	*1 Use	the FILAMENT TAPE	
13	A-8117-909-A \$ #	IFX-286 (S)			
14	4-670-314-01	SHEET (MS)			
15	4-670-294-03	ESCUTCHEON (JACK)			
18	4-669-735-01	ADHESIVE TAPE (16SH)			
19	4-661-451-01	ADHESIVE TAPE TOUCHPAD			
20	4-674-011-01	CUSHION (BT)			
21	4-675-270-01	SHEET (PW LED)			
22	1-824-946-11	CABLE, FLEXIBLE FLAT (SWX131)			
23	A-8117-902-A \$	SWX-131 (3) (S)			
24	1-687-010-12	PWB, FLEXIBLE PRINT (LED-W)			
25	4-673-768-01	SHEET (LED B)			
* 26	4-670-313-02	PLATE (PARM REST R)			

						J			Α	М				AO		
	D-f N	Dord No.		Description	Z1VT/P	Z1V/P	Z1VE	Z1VAP1 *	Z1VAP2 *	Z1VA *	Z1VFP	Z1VGP	Z1VLP	Z1VCP	Z1VTP	Z1VJP
		Part No.		Description			_								\vdash	
	1	1-234-803-21		BLUETOOTH MODULE	•	•	•	•	•	•					\vdash	-
	2	A-8117-910-A	\$ j	IFX-250 (3) (S)	•	•	•	•	•	•					\vdash	
	7	1-824-949-11		CABLE, FLEXIBLE FLAT (IFX250)	•	•	•	•	•	•					\vdash	
	10	X-4626-401-1	 	 HOUSING (PARM REST) ASSY				●.	•	•					ı	
<u> </u>		X-4626-402-1		HOUSING (PARM REST) ASSY							•	•	•		•	•
<u></u> [MA]	_ 16	4-678-382-01	 	 LABEL ID	•			ļ	ļ _	L _					ı	
		4-678-382-11	 	 LABEL ID	L _	•		ļ	ļ _	L _		l ₋ .			ı	
		4-678-382-21	 	 LABEL ID	L _		•	ļ	L _	L_		l			ı	
<u></u> (MA)		4-678-382-31	 	 LABEL ID	L _			ļ	L _	L_		•			ı	
<u> </u>		4-678-382-41	 	 LABEL ID	L _			l	_	L _		l	•		ı	
<u> </u>		4-678-382-51	 	 LABEL ID	L _			l	_	L_		l			ı	•
<u> </u>		4-678-382-61	 	 LABEL ID	L _			l		L_		L .	_		•	
<u> </u>	L	4-678-382-71	 	 LABEL ID	L_			l	L	L_		l		•	ıl	
<u></u> [MA]	L	4-679-371-01	 	 LABEL ID	L _			l		•		l			ı	
<u></u> [MA]		4-679-371-11		LABEL ID				•	•							
<u> </u>		4-679-371-21		LABEL ID							•				_	
	17	1-477-792-11	\$; #	KEYBOARD UNIT (JP)	•	•	•									
<u></u> [MA]		1-477-792-21	 #	 KEYBOARD UNIT (US)	Γ-			•	•	•		•	_	•		
<u> </u>		1-477-792-81	 #	 KEYBOARD UNIT (LA)	Γ			T - '	Γ		•					
<u></u> [MA]		1-477-792-91	 #	 KEYBOARD UNIT (KR)	Γ-			T - :	Ι-	Γ			•			
<u> </u>		1-478-193-11	 #	 KEYBOARD UNIT (TW)	Γ-			ļ — ·	T -	Γ-			_		•	
<u> </u>		1-478-193-21	 #	 KEYBOARD UNIT (TH)	T -			- :	T -	Γ			_			•
	29	A-8117-911-A	\$;	IFX-251 (3) (S)	•	•	•	•	•	•						
	30	1-827-266-21		CABLE, COAXIAL (WITH U.F.L CONNECTOR)	•	•	•	•	•	•						
•					\triangle			Δì	Λ	Λ	2	A	A	2	2	2
					[MA]			_[MA]	<u></u> [MA]	[MA]	[MA]	[MA]	(MA)	[MA]	[MA]	҈ [MA]

- This prts list contains two different types of parts.
 The fisrt type is the parts is theat are common to all models.
 The other type is the parts that are different depending on each model.
- The model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。

・機種名に(*)がつくのは CTO モデルです。



Ref.No.	Part No.		<u>Description</u>	Ref.No.	Part No.			<u>Description</u>
101 102	4-673-387-01 4-671-053-01	&	SHEET (BHF) SHEET (SCREW S)	133 134	4-670-335-02 4-671-074-01			LEVER, RELEASE LABEL (DOOR IO)
103	4-670-341-01	&	,	135	4-635-956-01			SPRING (B), COMPRESSION COIL
104	4-670-340-01	u	SHEET (BT)	136	4-670-338-02			KNOB (BR)
105	4-673-386-01		SPACER (P)	137	4-670-336-02			KNOB (BL)
100	+ 070 000 01		OF AGEIT (F)	107	+ 070 000 02			NNOB (BE)
* 106	4-670-328-01		BRACKET (HDR)	138	4-670-325-01		&	FOOT
* 108	4-670-327-01		BRACKET (HDL)	139	X-4625-671-2			DOOR (IO) ASSY
109	4-672-493-01		COVER (SC)	140	4-670-324-03	#		HOUSING (BOTTOM)
110	4-670-319-01		COVER (PR)	141	4-673-385-01			SHEET (GP)
* 111	4-670-333-01		LOCK (PR)	142				FILAMENT TAPE (W12X30) (*1)
			· ,					
112	4-662-881-02		CUSHION, KEY BOARD	143				CAPTON TAPE (W10X20) (*2)
113	1-825-310-12		SPEAKER, BOX WITH (2.3CM)	1 10				5/11 1 5/1 1/11 2 (W15/125) (2)
114	4-675-315-01		SHEET (K1035)	B1	4-672-839-01			HEAD, M3 FLAT
115	1-761-606-14		CARD, MODEM	B2	4-673-648-01			GRIP, M2 (+B) (EG)
116	1-687-012-11		PWB, FLEXIBLE PRINT (MODEM)	B3	4-676-936-01			+SCREW, M2 +SPECIAL HEAD SELF S
				В6	4-670-930-01		0	SCREW, +B EG GRIP
117	4-672-491-01		SHEET (FIN)					
118	1-400-255-11		FERRITE CORE	В7	4-672-834-81		&	SCREW, +B EG GRIP
119	4-674-429-01		THERMAL PAD (GFX)	-				0005144
120	4-670-320-01		SHEET (MDC)	B8	4-672-834-51		&	SCREW, +B EG GRIP
121	4-670-345-03		COVER (HINGE)	B9	4-673-646-01			DIA. (4.6) (M2)
				B10	4-673-647-01			M2 (+BSW)
122	4-670-322-04		BASE, DISPLAY	B13	4-671-538-01			SCREW (M2X4), SPECIAL HEAD
124	4-671-461-01		TAPE (M)	B16	4-672-834-91		&	SCRWE, +B EG GRIP
125	4-671-235-01		SHEET (M)					
126	1-962-037-11		HARNESS (RJ11)		the FILAMEN			L.
127	1-687-011-11		PWB, FLEXIBLE PRINT (OPT)	*2 Use	the CAPTON T	ГАР	E.	
* 128	4-670-346-01		BRACKET (ODR)					
129	X-4625-673-2		BEZEL (ODP) ASSY					
130	1-796-626-12 \$ #		COMBO DRIVE (UJDA745, 9.5MM)					
* 131	4-670-330-01		BRACKET (ODL)					
132	4-670-330-01		COVER (BT)					
132	4-070-310-03		OUVER (DI)					

[J			ΑN	VI				ΑО		
	Ref. No.	Part No.		Description	Z1VT/P	Z1V/P	Z1VE	Z1VAP1 *	Z1VAP2 *	Z1VA *	Z1VFP	Z1VGP	Z1VLP	Z1VCP	Z1VTP	Z1VJP
<u></u> [MA]	107	A-8067-943-A \$	#	ASSY HDD 80GB (I. 40) (S)	•				•							\neg
<u> </u>		A-8111-360-A \$	#	ASSY HDD 60GB (T. 30) (S)	-			-			- †	- 1	- •	•		
		A-8116-402-A \$	#	ASSY HDD 60GB (I. 40) (S)	Ι-	•		•		•	•	•			•	•
Ì		A-8116-404-A \$	#	ASSY HDD 40GB (I. 40) (S)	T -		•	-			- †	_				
<u></u> [MA]	123	1-761-660-13		CARD, WIRELESS LAN (CLX11B 11CH)				•	•	•	•				•	
<u></u> [MA]		1-761-660-23		CARD, WIRELESS LAN (CLX11B 14CH)							I	•	lacksquare	•		
		1-761-784-11		CARD, WIRELESS LAN	lacksquare	•	•									
	144	4-674-985-01		SHEET (MINI-PCI)	•	•	•									
<u> </u>	145	4-679-415-01		PLATE (UL) 1										•		
<u> </u>	146	4-676-302-01		TAPE (COMMON)										•		
<u> </u>	147	4-679-417-01		SPACER (UL) 1										•		
<u> </u>	148	4-679-416-01		PLATE (UL) 2										•		
<u> </u>	149	4-679-418-01		SPACER (UL) 2										•		
					[MA]			MA]	<u></u> [MA]		҈ [MA]	<u></u> [MA]	<u></u> [MA]	[®] [MA]	[®] [MA]	[MA]

- This prts list contains two different types of parts. The fisrt type is the parts is theat are common to all models. The other type is the parts that are different depending on each model.

 • The model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ・機種名に(*)がつくのは CTO モデルです。

M-1. Main Board




B2 (a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	205 204 B-1 220 B8 222 223 B11 219 B2 221 B-1 C B-1
	B2 204 B2 231 232 B2 234 B2 235 B2
PCG-Z1VAP2 239 B9 B-1 203 204 202 B66 B6	234 B-1 236 237 B-1 B-1

Ref.No.	Part No.	<u>Description</u>	Ref.No.	Part No.	Description
* 201	4-670-289-01	HEAT SPREADER	232	4-674-795-01	SHEET (DC)
202	4-671-078-01	SHEET (MEMO), THERMAL	233	1-961-978-12	HARMESS (WITH DC JACK 2P)
203	4-671-187-01	SHEET (HS)	234	4-673-671-01	THERMALPAD (FET)
204	4-662-881-02	CUSHION, KEY BOARD	235	4-673-670-01	THERMALPAD (COIL)
205	4-672-493-01	COVER (SC)	236	4-671-186-01	SHEET (BFAN)
206	1-687-009-11	PWB, FLEXIBLE PRINT (HDD)	* 237	4-670-291-01	BRACKET (FAN)
208	4-670-342-01	SHEET (PR)	238	4-671-077-01	SHEET (GFX), THERMAL
209	4-670-321-01	SHEET (PCC)			
210	1-694-760-21	JACK, SMALL TYPE	B2	4-673-648-01	GRIP, M2 (+B) (EG)
211	1-694-760-31	JACK, SMALL TYPE	B6	4-672-834-61	SCREW, +B EG GRIP
			B8	4-672-834-51	SCREW, +B EG GRIP
212	1-817-281-14	CONNECTOR, PC CARD	B9	4-673-646-01	DIA. (4.6) (M2)
213	4-670-343-01	SPACER (ETHER)	B11	4-635-966-01	SCREW (HEX)
214	A-8117-906-A \$	IFX-249 (3) (S)			
215	1-962-080-11	HARNESS, RJ-45	B12	4-673-751-01	NUT (M2) (TYPE2)
216	4-671-235-01	SHEET (M)			
217	A-8117-907-A \$	CNX-199 (3) (S)			
218	1-794-548-21	CONNECTOR, USB (A)			
219	1-824-973-11	CABLE ASSY			
* 220	4-670-331-01	BRACKET (USB)			
221	1-687-013-12	PWB, FLEXIBLE PRINT (VGA)			
222	A-8117-908-A \$ #	CNX-200 (3) (S)			
* 223	4-670-329-01	BRACKET (IO)			
224	1-756-038-11	BATTERY, NICKEL HYDROGEN			
225	4-642-711-01	SHEET (BATTERY), ADHESIVE			
226	4-674-010-01	THERMALPAD (MCH)			
220	10,101001				
227	4-673-971-02	SHEET (CPU)			
228	4-672-944-01	THERMAL SHEET (CPU)			
229	4-672-945-01	GUARD (FIN)			
230	1-763-964-12	DC FAN			
* 231	4-670-332-02	HOLDER (DC)			

ſ						J			Al	М				AO		
					Z1VT/P	Z1V/P	Z1VE	Z1VAP1 *	Z1 VAP2 *	Z1VA *	Z1VFP	Z1VGP	Z1VLP	Z1VCP	Z1VTP	Z1VJP
	Ref. No.	Part No.		Description				Z	Z							
<u></u> [MA]	207	A-8117-897-A \$	#	MBX-71 (B3) (S)	•				•							
Ī		A-8117-899-A \$	#	MBX-71 (C3) (S)	T -	lacksquare		•		•	•	•	•	•	•	•
Ī		A-8117-900-A \$	#	MBX-71 (D3) (S)	T -	Γ-	•		_					Ī -		
<u></u> [MA] [239	A-8067-880-A \$	#	COMPLETE PWB MM-10					•							
-					[MA]			[MA]	[MA]	[MA] ⊕	[MA]	[MA]	(MA) ⊕	[MA]	[MA]	[MA]
					≥			≥	≥	≥	2	≥	≥	\geq	2	\geq

- This prts list contains two different types of parts.
 The first type is the parts is theat are common to all models.
 The other type is the parts that are different depending on each model.
- The model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ・機種名に(*)がつくのは CTO モデルです。




Ref.No.	Part No.		Description
302 303 304	X-4625-667-3 4-671-221-02 4-670-189-01 1-754-292-12 4-669-620-03	& &	HOUSING (BEZEL) ASSY CAP (DOWN) CUSHION (UP) ANTENNA (2.4GHZ L AND R) HINGE (L)
307 308 309	A-8114-655-A \$ # 4-669-613-02 A-8114-751-A 4-669-615-03 4-669-622-01		LCD (UNIT) (14SXGA+) (S) COVER (WLL) DISPLAY ASSY (S) COVER (DISPLAY) MAGNET
312 313 314	4-669-614-02 4-669-612-02 1-477-753-11 4-675-311-01 4-673-641-01		COVER (WLR) COVER (CABLE) INVERTER UNIT SHEET (WLCL) SHEET (CORNER)
317 318 319	4-669-621-02 4-671-222-01 1-961-999-21 4-670-188-01 4-670-190-01	& &	HINGE (R) SHEET (LH) HARNESS, LCD (SXGA+) CUSHION (CENTER) CUSHION (SIDE)
	4-675-342-01 4-675-312-01		SHEET (HIS) ADHESIVE TAPE (WLCL) CAPTON TAPE (W10X30) (*2)
B3 B4 B8	4-673-648-01 4-676-936-01 4-672-834-71 4-672-834-51 4-672-834-91	&	SCREW, M2 (+B) (EG) +SCREW, M2 +SPECIAL HEAD SELF S SCREW, +B EG GRIP SCREW, +B EG GRIP SCREW, +B EG GRIP

^{*2} Use the CAPTON TAPE.

A-1. Accessories





















Ref.No. Part No. Description

△ 801 1-477-749-51 \$ & ADAPTOR, AC

					J			Α	M		AO						
	Ref. No.	Part No.			Description	Z1VT/P	Z1V/P	Z1VE	Z1VAP1 *	Z1VAP2 *	Z1VA *	Z1VFP	Z1VGP	Z1VLP	Z1VCP	Z1VTP	Z1VJP
<u> </u>	<u></u> ∆802	1-782-476-22		&	CORD, POWER											\dashv	\dashv
ZZZ [1417 t]		1-790-732-32		<u>~</u> _	CORD. POWER	•			- +								
†	803	A-8114-136-A	\$	&	BP2V (J) ASSY (S)	•	•	•								\dashv	
<u></u> (MA)		A-8114-137-A	- - -		BP2V (U) ASSY (S)				•		•	•			-		
(MA]		1-756-328-22	\$ -		BATTERY PACK, LITHIUM ION (PCGA-BP2V)				- †				•	•	•	•	•
<u></u> [MA]	 ∆804	1-757-562-21		&	CORD, POWER				•	•	•	•				•	\neg
<u></u> [MA]	∆ 805	1-555-074-31		&	CORD, POWER								•				
<u></u> [MA]	∆ 806	1-575-131-61		&	CORD, POWER								•				•
<u></u> [MA]	∆807	1-823-947-32		&	POWER-SUPPLY CORD									•			
<u></u> [MA] [∆ 808	1-770-019-12		&	ADAPTOR, CONVERSION PLUG 3P								•				
<u></u> (MA)	809	A-8114-139-A	\$	&	BP4V (U) ASSY (S)					•							
<u></u> (MA)		4-679-331-01		_&_	QUICK START, 2800UA				•	•	•						
		4-679-384-01		_&_	INSTRUCTION MANUAL (XP Professional, XP Home Edition)	•	•	•	_						L _ l		
<u> </u>		4-679-642-11		_&_	SPEC SHEET, 2800LA												
<u> </u>		4-679-643-11		_&_	QUICK START, 2800LA				_	_		•					
<u></u> [MA]		4-679-658-11			INSTRUCTION MANUAL (XP Professional)	L _			_				•		L _ l		•
<u></u> (MA)		4-679-658-21		_&_	INSTRUCTION MANUAL (XP Professional)	L _			_					•	L _ l		
<u> </u>		4-679-658-41		&	INSTRUCTION MANUAL (XP Professional)	L _			_						L _ l	•	
<u> </u>	_	4-679-659-31		&	INSTRUCTION MANUAL (XP Professional)										•		
						[MA]			<u></u> [MA]	[MA]	[MA]	<u>[MA]</u>	(MA)	(MA) ∀	[MA]	[®] [MA]	[MA]

- This prts list contains two different types of parts.
 The fisrt type is the parts is theat are common to all models.
 The other type is the parts that are different depending on each model.
- The model that is accompanied by asterisk (*) is the CTO model.
- ・この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ・機種名に(*)がつくのは CTO モデルです。

DIP Switch

The DIP switch setting is following table.

DIP スイッチの設定は下の表をご覧ください

Set the DIP switch on the MBX-71 board (Main board) to match with the LCD that is used in this computer. MBX-71 Board (メインボード) のDIPスイッチは、下図のように本機で使用するLCDに合わせて設定します。



The lower position where ON indication is shown is the ON position. The upper position is the OFF position.

下側(ONと表記のある側)がON, 上側がOFF

No.	1	2	3	4							
ON/OFF	1	0	1	1							
0	0:ON 1:OF										


CHAPTER 5. OTHERS

5-1. The Barcode Label


The half-tone dot meshing part will be used as repair data.

バーコードラベルの網掛け部は、修理データとして使用いたします。


[Main Section] (Bottom)




[COMBO Drive] (Top)




[HDD] (Top)




[MBX-71 Board] (Side A)




[LCD] (Bottom)





[KEYBOARD] (Bottom)



A : Part No.B : Serial No.C : Revision No.D : Product Code

E : Maker Barcode

F : Global User ID (iLink)
G : Mac Address

: Barcode

5-2. CTO Information △[MA]

1. PCG-Z1VA/Z1VAP1/Z1VAP2

PCG-Z1V Series CTO Component List Ver.1.0

The parts marked "O" are commonly used in all models. For the component of the parts that are not shown here, please refer to the PCG-Z1V* Service Manual.

Oserfier metice De		Product Code	28156630	28156530	28156930				
Configuration Parts		Model Name		PCG-Z1VA	PCG-Z1VAP1	PCG-Z1VAP2			
M/B	MBX-71 (B3) (S)	(CPU:1.7Ghz/Memory (On-Board):512MB)	A-8117-897-A	-	-	0			
IVI/D	MBX-71 (C3) (S)	(CPU 1.6Ghz/Memory (On-Board):512MB)	A-8117-899-A	0	0	-			
HDD	80GB		A-8067-943-A	-	-	0			
טטוו	60GB		A-8116-402-A	0	0	-			
LCD	14SXGA+		A-8114-655-A	0	0	0			
Expansion Memory	512MB		A-8067-880-A	-	-	0			
Battery	BP2V		A-8114-137-A	0	0	-			
Dattery	BP4V		A-8114-139-A	-	-	0			
Opt.Drive	COMBO DRIVE		1-796-626-12	0	0	0			
W-LAN	Available		1-761-660-13	0	0	0			
Bluetooth	Available		-	0	0	0			
Office	Bundle		-	-	-	-			
OS	WinXP Pro		ı	-	0	0			
03	WinXP Home		-	0	-	-			



List of PCG-Z1 Series (As of October, 2003)

Service Manual		Model	Name	
Parts No.	J	АМ	EU	AO
9-876-075-XX	PCG-Z1/P PCG-Z1T/P			
9-876-076-XX		PCG-Z1A		
9-876-078-XX		PCG-Z1FP		
9-876-077-XX			PCG-Z1M PCG-Z1MP PCG-Z1SP	
9-876-079-XX				PCG-Z1GP
9-876-080-XX				PCG-Z1LP
9-876-331-XX	PCG-Z1R/P PCG-Z1RT/P			
9-876-339-XX		PCG-Z1RA		
9-876-340-XX			PCG-Z1RMP PCG-Z1RSP	
9-876-332-XX				PCG-Z1RGP
9-876-333-XX				PCG-Z1RLP
9-876-335-XX				PCG-Z1RCP
9-876-334-XX				PCG-Z1RTP
9-876-345-XX	PCG-Z1VT/P PCG-Z1V/P PCG-Z1VE	PCG-Z1VAP1 * PCG-Z1VAP2 * PCG-Z1VA * PCG-Z1VFP		PCG-Z1VGP PCG-Z1VLP PCG-Z1VCP PCG-Z1VTP PCG-Z1VJP

*: CTO model
:: Additional Models

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部, または全部について, 無断で データの複製, 複写, 転載することを禁じます。

Revision History

Suffix	Ver.	Date	Contents	QM No.
-01	Ver. 1	2003.09.18	First Edition	
-02	Ver. 2	2003.10.06		N2003_066AK
-03	Ver. 3	2003.10.23		N2003_081AK
<	:Remarks	;>		